

User Manual

SV103 395nm UV Flashlight



Catalogue

1, Package Content	2
2, Install Battery	3
3, How to use the product	4
4, How to charge the battery	5
5. Application.	6

1, Package Content.



- 1 x 395nm UV Flashlight
- 1 x Rechargeable Battery
- 1 x USB Cable

When you receive your package, please check the package content at the first.

2, Install Battery



Battery Polarity: The positive (+) ends of the battery goes at the front (nearest to the bulb), and the negative (-) ends at the back of the torch.

It is recommended to fully charge the flashlight before first use.

Tips: Please remove the transparent plastic insulating film(if exists) covering the positive and negative surfaces of the battery before use

3, How to use the product



Power Switch

Press heavily the power button to turn on/off the flashlight.

4, How to charge the battery



Support USB C rechargeable function, Type C USB charging port with reversible, can be inserted into the power supply without regard to the front and back of the plug, which makes charging more convenient and fast. The high-capacity rechargeable battery is included.

Support USB direct charging, no charger required. You can charge it from the power adapter, computer, power bank or car charger.

Charging Indicator(The switch is the indicator)

Red: Charging

Green: Fully charged

Charging Specification: 5V-1A/2A

Charging Time: 4~5 hours

Battery Life: 1~1.5 hours

Tips: When the flashlight battery is too low (the light is dim), it is recommended that you charge it in time to avoid damage to the battery caused by over-discharge.

5. Application.

Fluorescent substances can emit light under ultraviolet light, using this principle, this product can be used for banknote authenticity detection, pet urine detection, mineral detection, etc.

