

User Manual

SV133 UV Flashlight



Catalogue

1, Package Content	2
2, Install Battery	3
3, How to use the product	4
4, How to charge the battery	5
5. Application	6

1, Package Content.



- 1 x 365nm UV Flashlight
- 1 x Rechargeable Battery
- 1 x USB Charging Cable
- 1 x UV Protective Glasses

Tips: When you receive your package, please check the package content at the first.

2, Install Battery



Please refer to the image above to install the battery.

Battery Polarity: The positive (+) ends of the battery goes at the front (nearest to the bulb), and the negative (-) ends at the back of the torch.

Tips: Please remove the **transparent** plastic insulating film(if exists) covering the positive and negative surfaces of the battery before use

3, How to use the product



Power Button

Press heavily the power button to turn on/off the flashlight.

Work Mode: 1 mode

4, How to charge the battery



This 365nm UV light is designed with a **USB C** charging port, it can be inserted into the charging port without regard to the front and back of the plug, which makes charging more convenient and easy.

Charging Indicator

Red: Charging

Green: Fully charged

Charging Time: 5~6 hours

Battery Life: 2~4 hours

Tips: When the flashlight battery is too low (the light is dim), it is recommended that you charge it in time to avoid damage to the battery caused by over-discharge.

5. Application.

The black light for pet urine detection is powerful and long-lasting, suitable for detecting fluorescent substances not visible to the naked eye, including cat pee/pet urine checking, cat ringworm detection, currency authentication, scorpion detection, mineral detection, bed bug detector, ID checking. This blacklight flashlights is great for curing resins, curing glue, and more!

If you have any questions with this product, please feel free to contact us at support@alonefire.com

